

Simple Induction Hob Instructions

1. Make sure wall switch is on.
2. Press power icon on hob
3. Select cooking zone
4. Use slider or +/- to alter power.
5. Turn off after use

Beware the Locking/safety mechanism. If you lock the hob (possible inadvertently) by pressing the padlock icon, LO will appear. To reset, just hold down the padlock button for a few seconds

All pans in the barn should be compatible with induction hobs – if you have brought you own, it might not be suitable.